



Important Note

IP66 IK06

To ensure proper installation, kindly translate / communicate the installation instructions to the local qualified electrician in their respective local language.



/ Warning

The safety of this fixture is guaranteed only if you comply with these instructions; Remember to store in a safe place before installation



Installation

- The luminaire must be operated with the complete protective cover.
- Do not open the front plate of light output opening of LED directly during installation.
- Push luminaire with earthspike vertically into the soil until stability is achieved. If necessary compact soil around the earth spike or fix the mounting bracket with suitable fixing screws onto the mounting surface.
- The location of installation may be revised to suit the site conditions especially considering the expected water stagnation levels.
- · We recommend to drain the mounting area to ensure no water logging at all times, also considering durations of heavy downpour.
- Use only flexible supply cables of suitable rating and diameter with the right IP rated. Do not use hard cables or armoured cables (Hard cable could effect the IP rating of the product)
- · Loosen joint screw and adjust the slope angle of the light. Tighten joint screw when desired angle is achieved.
- Please ensure that the wires are connected to the right polarity [Phase, Neutral & Earth] and the luminaire must be earthed (Class 1)

Safety

- · For Safety, always ensure power supply is disconnected before regular maintenance, lamp replacement and accessory fitting.
- Installation and operation of this luminaire are subject to national safety regulations. The manufacturer is discharged from liability when damage is caused by improper use or installation.
- · Any modification to this fixture without authorizaton will void all warranty.
- · Observe precautions for handling LED module.
- Do not subject the product for voltage or current which is not rated for.
- · Luminaire not suitable for direct mounting on normally flammable surfaces

Important Note:

- · LEDs are highly sensitive electronic components. Please avoid touching the light source directly, during installation.
- If fixture is supplied with integrated LED module, **Do Not Open** the front plate of luminaire during installation. Warranty void if the LED compartment is opened.

Maintenance Recommendations

- After installation, the luminaire should be cleaned first.
- Building dust, residues from pressure-sensitive adhesives, paint splatter and rust film must be completely removed. Never use cleaning implements made of normal steel, steel brushes or steel wool because they cause extraneous rust to form.
- Cleaning agents containing hydrochloric acid and chlorides should never be used.
- · We recommend cleaning the luminaires regularly.
- · Do not use high pressure cleaners.

Storage

If site is not ready for installation, store the material in proper warehouse facilities. K-Lite is not responsible for the damages caused due to the mishandling of material at site.

Customer Service

If Klite agrees to receive back some fixtures for Lab Testing and further analysis please ensure that the fixtures shipped should NOT BE DISASSEMBLED. Disconnect the power line and ship the product as is, unless otherwise specified.

Please contact customercare@klite.in for more information.